




**pop easy/square -** Supporting service cabinets**FREZZA®**





	165.094	187.976 ZN	187.915	1846014	187.911	174.110 ZN
 L 1200	X 4	X 4	X 4	X 2	X 2	X 1
 L 1650	X 4	X 4	X 4	X 2	X 2	X 1







# pop easy/square - Supporting service cabinets

**FREZZA®**

**03A**




**03B**



# pop easy/square - Supporting service cabinets

**FREZZA®**

**04A**




L 1200 (P 600 )




187.911  
X 1



174.110 ZN  
X 1




**04B**



L 1200 (P 800 )




187.911  
X 2




## pop easy/square - Supporting service cabinets

**FREZZA®**


**04C**




L. 1650 (P 600 )



187.911  
X 2



**04D**






L. 1650 (P 800 )



187.911  
X 1



174.110 ZN  
X 1



-Per disassemblare il prodotto seguire le istruzioni di assemblaggio a ritroso, invertendo il senso delle frecce.

-To disassemble the product, please follow the assembly instructions in the opposite order, reversing the arrows' direction.

-Pour démonter le produit, suivez les instructions de montage en sens inverse, en inversant le sens des flèches.