








pop easy/square - Starting desk for bench**FREZZA®**

	141.263	141.262	141.269	165.094	187.976 ZN	187.915	1846014
	EA X 4 X 2	EA X 4 X 2	PA X 2 PW X 2	X 24	X 24	X 24	X 12



pop easy/square - Starting desk for bench**FREZZA®**

ASSEMBLAGGIO
ASSEMBLY
ASSEMBLÉE

DISASSEMBLAGGIO
DISASSEMBLY
DÉMONTAGE

-Per disassemblare il prodotto seguire le istruzioni di assemblaggio a ritroso, invertendo il senso delle frecce.

-To disassemble the product, please follow the assembly instructions in the opposite order, reversing the arrows' direction.

-Pour démonter le produit, suivez les instructions de montage en sens inverse, en inversant le sens des flèches.