






pop Panel



|  |         |         |         |            |         |         |         |
|--|---------|---------|---------|------------|---------|---------|---------|
|  |         |         |         |            |         |         |         |
|  | 162.338 | 162.019 | 141.216 | 187.668    | 162.046 | 147.011 | 187.712 |
|  | X 6     | X 6     | X 2     | X 6        | X 6     | X 2     | X 2     |
|  |         |         |         |            |         |         |         |
|  | 187.771 | 187.772 | 187.382 | 808.050.FG |         |         |         |
|  | X 2     | X 2     | X 4     | X 2        |         | X 2     | 20 min  |




pop Panel




pop Panel



07





08



pop Panel



09-10-11-12



ASSEMBLAGGIO  
ASSEMBLY  
ASSEMBLÉE



DISASSEMBLAGGIO  
DISASSEMBLY  
DÉMONTAGE

-Per disassemblare il prodotto seguire le istruzioni di assemblaggio a ritroso, invertendo il senso delle frecce.  
-To disassemble the product, please follow the assembly instructions in the opposite order, reversing the arrows' direction.  
-Pour démonter le produit, suivez les instructions de montage en sens inverse, en inversant le sens des flèches.